


IPSO040

Disconnecting key
Chiave sgancio tubo



| Code | ØD1 | ØD2 | L |
|---------|-----|-----|----|
| IPSO040 | 8 | 14 | 93 |