


Seal Kit For Bronze Valves Actuator Ø 63/90

Maintenance operations must be carried out by qualified personnel according to manufacturer's instructions. To replace seals, please refer to the instruction manual provided with the valve.


Normally Closed



SPARE PARTS KIT:
Lip seal, o-rings, main seal, flat seal

Kit Code	DN	Valve Type ¹	Actuator
856 112 00-	15	CG/RCG/BCG- CN/RCN/BCN-	Ø 63
856 123 00-	20		
856 134 00-	25		
856 145 00-	32		
856 156 00-	40		
856 167 00-	50		
856 612 00-	15	DCG/DCN-	
856 623 00-	20		
856 634 00-	25		
856 645 00-	32		
856 656 00-	40		
856 667 00-	50		
856 317 00-	25	CG/RCG/BCG- CN/RCN/BCN-	Ø 90
856 318 00-	32		
856 319 00-	40		
856 320 00-	50		

Normally Open



STEM SEALS KIT

Kit Code	DN	Valve Type ¹	Actuator
856 802 00-	all	CG/RCG/BCG-/DCG- CN/RCN/BCN/DCN-	Ø 63/90

1. Included versions with optional: stroke regulator (e.g. code CG2065TXB0) and travel switch version (e.g. code BCG210LTJ0)

Seal Kit For Bronze Valves Actuator Ø 45

Maintenance operations must be carried out by qualified personnel according to manufacturer's instructions.
To replace seals, please refer to the instruction manual provided with the valve.

Normally Closed

Normally Open

